

# ST-550EAJ Power connector




ATX 20 +4 pins main power connector x1



8 pin Processor Power connector x 1




6 pin PCI Express power connector x 2



4 pins ATX 12V connector x 1  
( Processor power connector )



4 Pins Power connector x 6



Floppy connector x 2



5 pins SATA connector x 2



Power fail cable x 1